



A. & H. Meyer Sdn Bhd (528797-M)

No. 3, Jalan Astaka U8/84 Section U8, Bukit Jelutong 40150 Shah Alam, Selangor Malaysia

T: +60 3 7845 7277 W: www.ah-meyer.com.my E: sales@ah-meyer.com.my

## Installation Guide



Drop the box to the pre-cut table.



Ensure the box is sitting flush on the table.



Apply the 4 mounting clips to the box accordingly.

## Additional Mounting for Monitor Arm



- Lead the screw from the bottom through the bracket and line by using the reduction-ring (M10/M8/M12).
- 2. Fix the mount to screw and bring it into position.
- 3. Use a suitable tool to mount the monitor arm.

For dimensions Please refer to the back.



A. & H. Meyer Sdn Bhd (528797-M)

No. 3, Jalan Astaka U8/84 Section U8, Bukit Jelutong 40150 Shah Alam, Selangor Malaysia

T: +60 3 7845 7277 W: www.ah-meyer.com.my E: sales@ah-meyer.com.my

## Dimensions

**NETBOX** Line









[	М	2	3	4	5	6	7	8	9	10	Quantity of module outlets
	Α	140	193	246	299	352	405	458	511	564	Installation Length
	В	168.2	221.2	274.2	327.2	380.2	433.2	486.2	539.2	592.2	Total length with profile
[	С	140.5	193.5	246.5	299.5	352.5	405.5	458.5	511.5	564.5	Length of Cut out

\*All measurements are in mm



For Installation Guide Please refer to the back.